Giant Prize Pod
instructions

★ Please read the manual before using the machine !

Keep the manual in good condition !

accessories

1 key

2 instructions

3 power line

4 microswitch

5 other

Matters needing attention

This machine is for indoor use. Do not place outdoors.
Located indoors and should be avoided
Avoid the following conditions:
1 damp places
2 combustible or volatile matter around
3 sloping ground
Around 4 emergency exits, fire extinguishers and other fire fighting equipment
5 vibrate violent place
Be sure to turn off the power supply when maintenance, avoid electric shock or short circuit accident
8 without the company staff permission, does not tear open outfit,
To change or modification. In order to avoid improper operation or threat of damage products
Players and the safety of the people around you
9 attention to regular inspection and maintenance of this machin
10, when not mentioned in this manual, please be sure to relate thisThe company, According to the staff instructions.

Mainboard introduced



Mainboard introduced



1	10
2	11 standby normally on
3 joystick forward instructions	12
4 rocker backward directions	13
5 rocker instructions to the left	14
6 a handle to the right instructions	15 standby normally on
7 scissors forward instructions	16 standby normally on
8 setup instructions	



The mainboard normal standby mode

Normal blinking

Motherboard wiring instructions



J3 MOTOR12V



J4 note: Count light eye



J5 Other

Motherboard wiring instructions



J1-2 External interface of volume knob

J6 Liquid crystal connector



J2 Motherboard power supply



J1 2510-2P The horn line

Motherboard operation (Settings) instructions

Under the normal standby screen, long press the "MODE" key to enter the setting (main menu).

Standby screen



Select the entry item by pressing the key plate up and down, press the confirm key to enter the setting, and press the + key for 2 seconds to open the door





menu

Motherboard operation (Settings) instructions

A General Settings



Coin per play
Just throw in a few game COINS and play it once

Game time
Time per game

Music
You can set on or off

Switch storage
Optional to close
If I pick a number that's what thenumber is,It's how many COINS you put in a row and you get one

Volume
The bigger the number, the louderthe voice

Num.coins/bonus
You can set on or off The number of COINS left on the machine after shutdown and restart will be reset



Motherboard operation (Settings) instructions

Scissors Settings

(this has been adjusted, the guests do not need to adjust)

B1: scissors adjustment

The size of the scissors opening is 1-50.
The larger the value, the larger the opening.

B2: Location
That is, the winning position, the left and right buttons of the button can adjust the value of the value,The value 0750-0860 is adjustable, the larger the value, the higher the scissors.

Location(Special instructions):
Click MOED here to enter the winning position for debugging.

steps:
Press + button, scissors automatically forward, scissors stop position is the winning position, at this time must ensure that scissors can cut to the hanging gift rope

Motherboard operation (Settings) instructions

Motor speed: (Please press the machine default value for this item.)



Front and rear motor speed (Optional 1-5), The larger the value, the faster the motor rotation。

Prize setup:



Mode:fixed way

Selling way

x1 N times out:Just throw in a few game COINS and play it once

Vending N out:When you choose the sale mode, The set value represents how much money to make a gift

Motherboard operation (Settings) instructions

Machine test



Factory test only

Accounts



T income:the total amount of money invested in the machine throughout its history
T payout:The total number of gifts given out in the historyof the machine
C income:The amount of money invested since the last closing of accounts
C payout:Gifts given since the last closing of accounts
Total plays:The last prize has been awarded to players so far

Accounts reset



Native is to clear the accounts, The clearing content is:C income/ C payout/Total plays

Motherboard operation (Settings) instructions

Free play

Self test, remember to close before business!!!

Factory reset



Try restoring factory Settings when a failure cannot be resolve

Language

Chinese and English optional